


## Reporting you Hardware Configuration in Dialog 5


You can find and save the information about the hardware present in your Logger by using the Diagnostics Tab of the Reflash window. The Logger must be on and connected to the PC, the Rebel Drivers must be loaded, The 'Reflash window' is accessed using the **Logger Tab** and menu button as shown below:



The 'Reflash' window is shown below. The window opens with the 'Firmware' tab as default.



The Diagnostics Tab shown below allows you to easily identify your exact configuration:



If you use the Save button you can save this information to a file so you can share the information with others.